

Montering dörrfront

Isotherm kylskåp 42 till 120 liter kan kompletteras med en till inredningen anpassad dörrfront. Som tillbehör finns fronter i vitt, mahogny, teak och körsbär.

Montering:

Lossa dörrlåsets tre fästskruvar, se fig. 1, två på framsidan och en i underkant av greppet så att den nya fronten kan glida in under dörrlåseslaget.

Lossa listen i dörrens underkant, se fig 2, med hjälp av kniv eller skruvmejsel. Listen dras av rakt ut från dörren.

Låt original grå dörrfront sitta kvar, den nya dörrfronten skjuts in över den grå skivan.

Tryck fast den nedre listen igen med händerna.

Skruva fast dörrlåset igen på samma plats som förut.

Mounting door panel

Isotherm refrigerators 42 to 120 litres can be equipped with additional door panels to suit various boat interiors. They are available as accessories in white, mahogany, teak and cherry.

Mounting:

Unscrew the door grip, it is hold in position by means of three screws two on the face and one from underneath. See fig. 1.

Take off the strip on the lower edge of the door. See fig. 2. Use a knife or a screwdriver to loosen it and pull off the strip by hand.

Let the original grey panel stay in place and slide in the new panel in front of the grey one.

Put back the strip, push it on by hand.

Fasten the door grip with the three screws again, in the same position as before.

